



MANUAL

INKLINATOR CMI PRODUCTION No boom

	Page
1. General description	2
2. General data	3
3. Function Master	4
4. Mounting instructions	5
5. Checking the system	6
5.1 Application program	6
5.2 Transducer nodes	6
5.3 Checking transducers	7
6. Zero setting	7
7. Operator settings	8
8. Test of output signals	9
9. Test of input signals	9
10. Trouble shooting angle system	10
11. Trouble shooting length system	10
12. Setting of system	11
13. Checking and setting summary	14
Signal cable connection	15
Electric connection drawing	16

TRANSTRONIC AB

Box 175
S-731 24 KÖPING
SWEDEN


Phone +46(0)221-84770

Fax +46(0)221-19050

1 GENERAL DESCRIPTION

The **INKLINATOR** CMI Production is designed to for non boom production drill rigs. The CMI Production no boom is a **modular- built system** showing, controlling and collecting drilling-related information. This improves the quality and accuracy of the drilling operation which in turn improves productivity and working conditions for the operator and in all subsequent operations in the quarry or open pit.

CMI Production	Basic instrument for angle measurement of rotation and inclination
Module Length	For measuring hole length and penetration rate. There is also a length stop the drilling when preset length is archived. Note that drill rig has to handle that signal.
Module Logging	For communication with logging instrument (For special orders, not incl. in this manual.)



The picture shows one CMI Production Rotation and Inclination angle measurement.

2 GENERAL DATA

Power supply	24V DC
Power consumption	0,2A
Working temperature	-20 - +50 ° C
Environmental protection	IP65


Angle measuring:

Measurement range inclination	± 60°
Measurement range rotation	360°
Accuracy	± 0,3 °

Hole length/penetration rate measuring:

Measurement range hole length	0 - 99.9 m, 0 – 99' 11''
Measurement range penetration rate	0 - 9.99 m/min, 0 – 32' 7''/min
Accuracy length measurement	±1%, min 0.05 m

3 FUNCTION MASTER



On/Off Switch. Turns the system On/Off.

Σm (total) button. When pressed the total length (drilled in rock) is shown on the lower display. On the upper display the actual rate of penetration is shown.

To zero set press both Total (Σm) button and Reset (//) button at the same time.

Note: Angle/Pause/Length mode switch has to be in mode Length.

Reset // button. When pressed length measured for the last hole is zeroed.

Note Angle/Pause/Length mode switch has to be in mode Length.

Angle/Pause/Length mode. If the switch is in Angle mode: the system shows angles.

Lower display is rotation angle and upper display inclination angle. **Note:** All angles refer to the direction the sight is pointing. If checking angles while drilling, the system will continue to measure the length of the hole being drilled, while in Angle mode.

If the switch is in Pause mode: both displays will show '----'. **Note:** In this mode, the system will stop measuring length. Hence, if the driller wants to stop measuring length to avoid any hole length errors, e.g. during flushing a hole with percussion and assuming percussion is being used as a drilling signal, then this mode can be used.

If the switch is in Length mode: the system shows the rate of penetration on the upper display (updated every 3 seconds) and the position of the bit from the collar (or laser line) on the lower display.

Automatic system check.

The system has an automatic monitoring which checks that the master is communicating with all transducers in a proper way. If a cable is broken or if a transducer fails the upper display will show "Err" the lower display will show the node no which fails. If more than one node is failing the display will toggle between the faulty node numbers. If the master doesn't have contact with any transducer the display will show "OFF".

4. Mounting instructions.

Master

These shall be mounted in a protected place where the operator can reach and see them. The central unit shall be connected to a clean stable 24 V DC source. In most cases the rig's battery is the best choice.

The cable shall be protected by a fuse.

Rotation transducer

The rotation transducer shall be mounted in the transducer protection.

Mount the Transducer and Transducer protection for rotation angel measurement on the feeder holder on a place where it is well protected during drilling.

Inclination transducer

The Inclination transducer shall be mounted in the transducer protection.

Mount the Transducer and Transducer protection where it measures the inclination angel.

I ex The tilt unit for the rotation.

Length transducer

Standard length transducer:



Mount the length transducer on the feeder on the opposite side to the drifter with the chain wheel pointing downwards in a place where it can link into the feeder chain.

Rig-specific length transducer:

Measure the distance from the chain wheel to the cover's mounting plate (A). Check that the two proximity switches are placed at a distance 2 mm less than the distance A.

If the distance is incorrect, loosen the switches and adjust to right distance.

Do not tighten the nuts too much. Max torque 25 Nm (18 lb-ft).



Cylinder Feeder.

Contact Transtronic AB

Cables

The cables to the front transducers are protected by hydraulic hoses. Both ends of the hoses must be fixed with the supplied bracket which shall be welded near the transducer.

The hoses shall be placed together with the other hoses on the boom.

5 Checking of the system

5.1 Application program.

Make sure that the switch Angle/Pause/Length is in position Angle. (Left).

Turn the system off.

Press the reset // button down and hold it.

Turn the system on.

Release the reset // button.

Now the upper display shows 9999

Lower display shows 0

Press Σ m (total).

Upper Display	Lower display
9001	3

Lower display shows the selected application.

3 = Production underground

If not contact Transtronic AB.

Press Σ m (total).

5.2 Transducer nodes

Upper display shows transducer node number.

Lower display shows '1' if the transducer node is connected and '0' if not.

Press Σ m (total) to select next transducer node.

Upper Display	Lower display
01	Length transducer 1 = mounted 0 = not mounted
08	Inclination transducer. 1 = mounted 0 = not mounted
11	Rotation transducer. 1 = mounted 0 = not mounted

Mounted transducer's node shall be 1. All others shall be 0.

To change go to setting of the system. (Mounting instruction chapter 12).

Check that all connected transducers is in contact with the master.

5.3 Checking transducer directions.

Press Σm (total) several times until the upper display shows 16.

Press Σm (total).

Now the shows the values (after calibration) of the connected transducer.

If a transducer is not connected the system shows next transducer.

Upper Display	Lower display
1011	Length transducer counter. When the cradle is moved downwards the value shall increase.
1081	Inclination transducer When the feeder is vertical the shall be approx 0^0 ($\pm 3^0$). When the feeder is moved backwards the value shall be positive and when the feeder is moved to the forward the value shall be negative.
1111	Rotation transducer When the feeder is vertical the shall be approx 0^0 ($\pm 3^0$). When the feeder is moved to the right the value shall be positive and when the feeder is moved to the left the value shall be negative.

If any values count in the wrong direction go to setting of the system. (Chapter 12).

6. Zero Setting

Adjust the feeder to vertical in both inclination and rotation,

Turn the system off. (Not necessary if you already are already in trouble shooting mode - then continue to press Σm (total) until 2021 is shown.)

Press the reset // button down and hold it.

Turn the system on.

Release the // button.

Now the Upper display shows 9999

Lower display shows 0

Press Σm (total) several times until the upper display shows 2021

For zero setting of a transducer press reset // button.

To select the next transducer press Σm (total).

Upper display		Lower Display
2081	Inclination transducer.	0.0
2111	Rotation transducer.	0.0

7. Operator settings

Turn the system off. (Not necessary if you already are already in trouble shooting mode then continue to press Σm (total) until 3101 is shown.)

Press the reset // button down and hold it.

Turn the system on.

Now the Upper display shows 9999

Lower display shows 0000

Press Σm (total) several times until the upper display shows 3101

Upper display

3101

To save value press reset // button.

To change function press Σm (total).

Lower Display

Not in use

Drill rod length

Upper display

3102

Lower Display

Shows the maximal rod length.

Press down the +/- knob and turn it so it shows length of on drill rod.

0.0 is disconnection.

Upper display

3103

Lower Display

Shows the resolution in angle measurement.

Press down the +/- knob and turn to the resolution you want.

0.1, 0.2, 0.5 is the choice.

To save value press reset // button.

To change function press Σm (total).

8. Test of Output Signals

Turn the system off. (Not necessary if you already are in trouble shooting mode then continue to press Σm (total) until 3201 is shown)

Press the reset // button down and hold it.

Turn the system on.

Now the upper display shows 9999

Lower display shows 0000

Press Σm (total) several times until the upper display shows 3201

Upper display

3201

Lower Display

Shows nothing. When pressing // button the output signal becomes active (lower display will show '1').

9. Test of Input Signals

Turn the system off. (Not necessary if you already are in trouble shooting mode then continue to press Σm (total). until 3301 is shown)

Press the reset // button down and hold it.

Turn the system on.

Now the upper display shows 9999

Lower display shows 0000

Press Σm (total) several times until the upper display shows 3301

Upper display

3301

Lower display

Shows 0000. If an input gets active it changes to 1

Drilling signal 4	Drilling signal 3	Drilling signal 2	Drilling signal 1	Lower Display
0	0	0	1	0001
0	0	1	0	0010
0	1	0	0	0100
1	0	0	0	1000

Upper display

3401

Lower display

Shows 0 when the switch Absolute /Relative is in position Absolute.
Shows 1 when the switch Absolute /Relative is in position Relative

3501

Shows 0 when the switch Angle/Pause/Length is in position Angle.
Shows 1 when the switch Angle/Pause/Length is in position Pause.
Shows 2 when the switch Angle/Pause/Length is in position Length.

10. Troubleshooting angle system

Fault

Action

If a cable is broken or if a transducer fails the upper display will show “**Err**” the lower display will show the node no which fails. If more than one node is failing the display will toggle between the faulty node numbers.

If the master doesn't have contact with any transducer the display will show “**OFF**”.

The displays shows nothing.
And the lights in the displays
are off.

Check power supply to the master.
Should be between 22 and 28V DC.
(Input voltage)
If no voltage check the fuse.

Display for inclination or rotation unstable
or shows incorrect value.

Run the trouble shooting mode and try to locate the
faulty transducer. (See chapter 7.3)

Connect a spare (lose) cable to the faulty transducer.
If system now functions OK, change the signal cable
If not change the transducer.

If the measurement still doesn't work correct, change
the master.

11. Troubleshooting length system

Fault

Action

Length measurement doesn't work

Run the trouble shooting mode and try to locate the
fault. See chapter 7.3 (Upper Display 1011).

Missing signal from the length transducer.

Check the wire on the length transducer.
Check that the proximity switches in the length
transducer is ok by measuring voltage inside the
connection box on the feeder (if chain feeder used).
See drawing 06090830

If no drilling signals

Trouble shoot the control signal connections in the
Electrical cabinet. See drawing 06090830

12 Setting of the system

Here you tell the system witch transducer that is connected:

Turn the system off.

Press the reset // button down and hold it.

Turn the system on.

Release the // reset button.

Now the Upper display shows 9999

Lower display shows 0

Press down +/- knob and adjust so that you have 0099 on the lower display.

Press Σm (total).

If you what to change press down +/- knob and adjust to 0 or 1.

To save it press // reset button.

Go to next press Σm (total).

Function	Upper Display	Lower Display
Length Transducer	01	
Connected		1
Not connected		0
Press Σm (total).		
Inclination transducer	08	
Connected		1
Not connected		0
Press Σm (total).		
Rotation transducer	11	
Connected		1
Not connected		0
Press Σm (total).		
Press Σm (total) until 1011 on the upper display. Or the first connected transducer.		
Length transducer direction	1011	
Normal		0* (** is default)
Reversed direction		1
Inclination transducer direction	1081	
Normal		0*
Reversed direction		1
Rotation transducer direction	1111	
Normal		0*
Reversed direction		1

Press Σ m (total) until 5001 on the upper display.
Or the first connected transducer.

Chain selection for the length transducer 5002

cylinder feeder 1:2	1*
cylinder feeder 1:1	2
1"	3
1 1/4"	4
1 1/2"	5
1 3/4"	6
2"	7
1"Wire	8
Setting of measurement distance (mm)/pulse	0

To change to 10 of mm press Σ m. Press // to save value in the length transducer.

Drilling signals connection 5003

Only one drilling signal (e.g. percussion or rod handling) **1***

Drill 1 Drill 2

0 x Length measurement off

1 x Length measurement on

The normal way to Digital 1 is to mount a relay
over the hour counter for the drill hammer.

Both drilling signal 1 and 2 (Normally drilling rotation and air on) **2**

Drill 1 Drill 2

0 0 Length measurement off

1 1 Length measurement on

To get in to length measurement, both signals
Must be active.

To get out of length measurement mode both
signals must be inactive.

Not used: **3**

Hole length or hole depth 5004

Hole length **0***

Hole depth **1**

Type of length measurement mode 5005

Length of the hole **0**

(Shows the length of the drilled hole).

Position of the bit. **1***

(The system keeps a steady check of the position of bit).

Hammer type on rig	5006	
Top Hammer		0*
ITH hammer		1

If ITH hammer selected the system will show distance from hole bottom on the upper display and the position of the bit on the lower display when the rod from extracted in the hole.

Measurement units	5007	
Metric		0*
US		1

When using metric units the system shows hole length and total length in metres, penetration rate in metres/minute.

With using US units the system shows hole length and total length in feet and inches, penetration rate in feet and inches/minute.

By pressing Σ m (total) again the system will go to the start of the setup program again with 0099 on the lower display. This is useful for checking the setup.
If not, shut the system off

Not used	5008	
-----------------	-------------	--

15 Checking and setting summary

Checking No code

9000 Application

9001 Selected application program

- 1 Check of node
- 2 Check of node
- 3 Check of node
- 4 Check of node
- 5 Check of node

1000 Measurement values

1011 Length transducer
1012 Not used
1081 Inclination transducer
1111 Rotation transducer

2000 Zero setting

2081 Zero setting Inclination transducer
2111 Zero setting Rotation transducer

3100 Operator settings

3101 Not used
3102 Setting of rod length
3103 Measurement resolution

3200 Output signals

3201 Test of stop signal

3300 Input signals

3301 Check of drilling signals
3401 Check of switch Absolute/Relative
3501 Check of switch Angle/Pause/Lengt

Setup Code 99

- 1 Node on/off Length transducer
- 8 Node on/off Inclination transducer
- 11 Node on/off Rotation transducer

1000 Direction node

1011 Direction length transducer
1081 Direction Inclination transducer
1111 Direction Rotation Transducer

5000 System settings

5002 Selection of length transducer
5003 No of drilling signals
5004 Hole length/hole depth 0=length 1=depth
5005 Hole length/bit pos 0=hole length 1=pos bit
5006 Hammer 0=top 1=ITH
5007 Units 0=m 1=US
5008 GPS Compass Bench drilling

Signal cables connection

